

FYREYE MKII ADDRESSABLE INPUT/OUTPUT MODULE WITH ISOLATOR INSTALLATION GUIDE

General

The Fyreye MkII Addressable Input/Output Module is supplied with a backbox for surface mounting.

NOTE: The Input/Output Module is designed for indoor use only.

This product is loop powered and a maximum of 60 devices are allowed on any Zeta detection loop.

Model No: ZAIO-MI Fyreye MkII Addressable Input/Output Module With Isolator

Surface Mounting

- 1. Mount the backbox as required and install all cables for termination.
- 2. Set the address of the unit as shown on page 3.
- 3. Terminate all cables.
- 4. Gently push the completed assembly towards the back box until the mounting holes are aligned and secure with the two mounting screws provided. DO NOT OVERTIGHTEN.

Isolator Module

The ZAIO-MI Module is fitted with a bi-directional short-circuit isolator and will be unaffected by loop short-circuits on either loop input or output.


Status	LED Indication
Switch closed	Illuminated red when monitored field contact is activated
Relay on	Illuminated red when relay is energized
Fault	Illuminated yellow when the input is open or short circuit
Polling	Flashed green when the device is polled by control panel
Isolating	Illuminated yellow when the loop is short or wrong connection circuit

LED Indications


Wiring details

All wiring terminals will accept solid or stranded cables up to 2.5mm²


Interface to 3rd Party Panel




Door Magnet



Normally Open Contact





Technical Specification

Model	ZAIO-MI
Part Number	48-108
Operating Voltage	17-28V DC
Quiescent Current @ 24V	1.0mA
Switch Input Closed (LED OFF)	1.25mA
Relay Operated (LED ON)	2.0mA (Max 2 LEDs on)
Relay Rating	SELV @ 1A
Isolating Current	7.3mA
Input End Of Line	20k
Alarm Triggering Resistor	1k
Operating Temperature	-10°C to +55°C
Max Humidity	95% RH Non Condensing
IP rating	IP21C
Size (mm)	150 x 90 x 45
Weight	220g

For information on the short circuit isolator operation see document GLT-224-6-9 available from your distributor.

Address Setting

The address of the Input/Output Module is set using the eight segments of the DIL switch. Each segment of the switch must be set to "0"(ON) or "1"(OFF), using a small screwdriver or similar tool. A complete list of address settings is shown overleaf. The maximum address is 250.


S									S								
ADDRESS	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	ADDRESS	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
ADD	N I	N I	N I	N I	N I	N I	N I	N I	ADD	N I	N I	N I	N N	N I	N N	N I	S
0									64	ON	ON	ON	ON	ON	ON	OFF	ON
1	OFF ON	ON OFF	ON ON	ON ON	ON ON	ON ON	ON ON	ON ON	65 66	OFF ON	ON OFF	ON ON	ON ON	ON ON	ON ON	OFF OFF	ON ON
3	OFF	OFF	ON	ON	ON	ON	ON	ON	67	OFF	OFF	ON	ON	ON	ON	OFF	ON
4	ON OFF	ON ON	OFF OFF	ON ON	ON ON	ON ON	ON ON	ON ON	68 69	ON OFF	ON ON	OFF OFF	ON ON	ON ON	ON ON	OFF OFF	ON ON
6	ON	OFF	OFF	ON	ON	ON	ON	ON	70	ON	OFF	OFF	ON	ON	ON	OFF	ON
8	OFF ON	OFF ON	OFF ON	ON OFF	ON ON	ON ON	ON ON	ON ON	71 72	OFF ON	OFF ON	OFF ON	ON OFF	ON ON	ON ON	OFF OFF	ON ON
9 10	OFF ON	ON OFF	ON ON	OFF OFF	ON ON	ON ON	ON ON	ON ON	73 74	OFF ON	ON OFF	ON ON	OFF OFF	ON ON	ON ON	OFF OFF	ON ON
11	OFF	OFF	ON	OFF	ON	ON	ON	ON	75	OFF	OFF	ON	OFF	ON	ON	OFF	ON
12	ON OFF	ON ON	OFF OFF	OFF OFF	ON ON	ON ON	ON ON	ON ON	76	ON OFF	ON ON	OFF OFF	OFF OFF	ON ON	ON ON	OFF OFF	ON ON
14	ON	OFF	OFF	OFF	ON	ON	ON	ON	78	ON	OFF	OFF	OFF	ON	ON	OFF	ON
15 16	OFF ON	OFF ON	OFF ON	OFF ON	ON OFF	ON ON	ON ON	ON ON	79 80	OFF ON	OFF ON	OFF ON	OFF ON	ON OFF	ON ON	OFF OFF	ON ON
17	OFF	ON	ON	ON	OFF	ON	ON	ON	81	OFF	ON	ON	ON	OFF	ON	OFF	ON
18 19	ON OFF	OFF OFF	ON ON	ON ON	OFF OFF	ON ON	ON ON	ON ON	82 83	ON OFF	OFF OFF	ON ON	ON ON	OFF OFF	ON ON	OFF OFF	ON ON
20	ON	ON	OFF OFF	ON	OFF OFF	ON	ON	ON	84	ON	ON	OFF OFF	ON	OFF OFF	ON	OFF OFF	ON
21 22	OFF ON	ON OFF	OFF	ON ON	OFF	ON ON	ON ON	ON ON	85 86	OFF ON	ON OFF	OFF	ON ON	OFF	ON ON	OFF	ON ON
23	OFF ON	OFF ON	OFF ON	ON OFF	OFF OFF	ON ON	ON ON	ON ON	87 88	OFF ON	OFF ON	OFF ON	ON OFF	OFF OFF	ON ON	OFF OFF	ON ON
25	OFF	ON	ON	OFF	OFF	ON	ON	ON	89	OFF	ON	ON	OFF	OFF	ON	OFF	ON
26	ON OFF	OFF OFF	ON ON	OFF OFF	OFF OFF	ON ON	ON ON	ON ON	90 91	ON OFF	OFF OFF	ON ON	OFF OFF	OFF OFF	ON ON	OFF OFF	ON ON
28	ON	ON	OFF	OFF	OFF	ON	ON	ON	92	ON	ON	OFF	OFF	OFF	ON	OFF	ON
29 30	OFF ON	ON OFF	OFF OFF	OFF OFF	OFF OFF	ON ON	ON ON	ON ON	93 94	OFF ON	ON OFF	OFF OFF	OFF OFF	OFF OFF	ON ON	OFF OFF	ON ON
31	OFF	OFF	OFF	OFF	OFF	ON	ON	ON	95	OFF	OFF	OFF	OFF	OFF	ON	OFF	ON
32	ON OFF	ON ON	ON ON	ON ON	ON ON	OFF OFF	ON ON	ON ON	96 97	ON OFF	ON ON	ON ON	ON ON	ON ON	OFF OFF	OFF OFF	ON ON
34	ON	OFF	ON	ON	ON	OFF	ON	ON	98 99	ON	OFF	ON	ON	ON	OFF	OFF	ON
35 36	OFF ON	OFF ON	ON OFF	ON ON	ON ON	OFF OFF	ON ON	ON ON	100	OFF ON	OFF ON	ON OFF	ON ON	ON ON	OFF OFF	OFF OFF	ON ON
37 38	OFF ON	ON OFF	OFF OFF	ON ON	ON ON	OFF OFF	ON ON	ON ON	101 102	OFF ON	ON OFF	OFF OFF	ON ON	ON ON	OFF OFF	OFF OFF	ON ON
39	OFF	OFF	OFF	ON	ON	OFF	ON	ON	103	OFF	OFF	OFF	ON	ON	OFF	OFF	ON
40	ON OFF	ON ON	ON ON	OFF OFF	ON ON	OFF OFF	ON ON	ON ON	104 105	ON OFF	ON ON	ON ON	OFF OFF	ON ON	OFF OFF	OFF OFF	ON ON
42	ON	OFF	ON	OFF	ON	OFF	ON	ON	106	ON	OFF	ON	OFF	ON	OFF	OFF	ON
43	OFF ON	OFF ON	ON OFF	OFF OFF	ON ON	OFF OFF	ON ON	ON ON	107 108	OFF ON	OFF ON	ON OFF	OFF OFF	ON ON	OFF OFF	OFF OFF	ON ON
45	OFF	ON	OFF	OFF	ON	OFF	ON	ON	109	OFF	ON	OFF	OFF	ON	OFF	OFF	ON
46	ON OFF	OFF OFF	OFF OFF	OFF OFF	ON ON	OFF OFF	ON ON	ON ON	110 111	ON OFF	OFF OFF	OFF OFF	OFF OFF	ON ON	OFF OFF	OFF OFF	ON ON
48	ON	ON	ON	ON	OFF	OFF	ON	ON	112	ON	ON	ON	ON	OFF	OFF	OFF	ON
49 50	OFF ON	ON OFF	ON ON	ON ON	OFF OFF	OFF OFF	ON ON	ON ON	113 114	OFF ON	ON OFF	ON ON	ON ON	OFF OFF	OFF OFF	OFF OFF	ON ON
51 52	OFF ON	OFF ON	ON OFF	ON ON	OFF OFF	OFF OFF	ON ON	ON ON	115 116	OFF ON	OFF ON	ON OFF	ON ON	OFF OFF	OFF OFF	OFF OFF	ON ON
53	OFF	ON	OFF	ON	OFF	OFF	ON	ON	117	OFF	ON	OFF	ON	OFF	OFF	OFF	ON
54 55	ON OFF	OFF OFF	OFF OFF	ON ON	OFF OFF	OFF OFF	ON ON	ON ON	118 119	ON OFF	OFF OFF	OFF OFF	ON ON	OFF OFF	OFF OFF	OFF OFF	ON ON
56	ON	ON	ON	OFF	OFF	OFF	ON	ON	120	ON	ON	ON	OFF	OFF	OFF	OFF	ON
57 58	OFF ON	ON OFF	ON ON	OFF OFF	OFF OFF	OFF OFF	ON ON	ON ON	121 122	OFF ON	ON OFF	ON ON	OFF OFF	OFF OFF	OFF OFF	OFF OFF	ON ON
59	OFF	OFF	ON	OFF	OFF	OFF	ON	ON	123	OFF	OFF	ON	OFF	OFF	OFF	OFF	ON
60 61	ON OFF	ON ON	OFF OFF	OFF OFF	OFF OFF	OFF OFF	ON ON	ON ON	124 125	ON OFF	ON ON	OFF OFF	OFF OFF	OFF OFF	OFF OFF	OFF OFF	ON ON
62	ON	OFF	OFF	OFF	OFF	OFF	ON	ON	126	ON	OFF	OFF	OFF	OFF	OFF	OFF	ON
63	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON	127	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON

												r				1	r	
S										SS								
Ш.	5	SW2	SW3	SW4	SW5	SW6	5	SW8		Ш.	5	SW2	SW3	SW4	SW5	SW6	5	SW8
ADDRESS	SW1	S	S	S	S	S	SW7	S		ADDRESS	SW1	S	S	S	S .	S	SW7	S
AL										AL								
128	ON	ON	ON	ON	ON	ON	ON	OFF		192	ON	ON	ON	ON	ON	ON	OFF	OFF
129	OFF	ON	ON	ON	ON	ON	ON	OFF	1	193	OFF	ON	ON	ON	ON	ON	OFF	OFF
130	ON	OFF	ON	ON	ON	ON	ON	OFF		194	ON	OFF	ON	ON	ON	ON	OFF	OFF
131	OFF ON	OFF ON	ON OFF	ON ON	ON ON	ON ON	ON ON	OFF OFF		195 196	OFF ON	OFF ON	ON OFF	ON ON	ON ON	ON ON	OFF OFF	OFF OFF
133	OFF	ON	OFF	ON	ON	ON	ON	OFF		190	OFF	ON	OFF	ON	ON	ON	OFF	OFF
134	ON	OFF	OFF	ON	ON	ON	ON	OFF	1	198	ON	OFF	OFF	ON	ON	ON	OFF	OFF
135	OFF	OFF	OFF	ON	ON	ON	ON	OFF		199	OFF	OFF	OFF	ON	ON	ON	OFF	OFF
136	ON	ON	ON	OFF	ON	ON	ON	OFF		200	ON	ON	ON	OFF	ON	ON	OFF	OFF
137 138	OFF ON	ON OFF	ON ON	OFF OFF	ON ON	ON ON	ON ON	OFF OFF		201 202	OFF ON	ON OFF	ON ON	OFF OFF	ON ON	ON ON	OFF OFF	OFF OFF
139	OFF	OFF	ON	OFF	ON	ON	ON	OFF		202	OFF	OFF	ON	OFF	ON	ON	OFF	OFF
140	ON	ON	OFF	OFF	ON	ON	ON	OFF	1	204	ON	ON	OFF	OFF	ON	ON	OFF	OFF
141	OFF	ON	OFF	OFF	ON	ON	ON	OFF		205	OFF	ON	OFF	OFF	ON	ON	OFF	OFF
142 143	ON OFF	OFF	OFF OFF	OFF OFF	ON ON	ON ON	ON ON	OFF OFF		206	ON OFF	OFF OFF	OFF OFF	OFF OFF	ON ON	ON ON	OFF OFF	OFF OFF
143	OFF	OFF ON	OFF	OFF	OFF	ON	ON	OFF		207	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF
145	OFF	ON	ON	ON	OFF	ON	ON	OFF	1	200	OFF	ON	ON	ON	OFF	ON	OFF	OFF
146	ON	OFF	ON	ON	OFF	ON	ON	OFF]	210	ON	OFF	ON	ON	OFF	ON	OFF	OFF
147	OFF	OFF	ON	ON	OFF	ON	ON	OFF		211	OFF	OFF	ON	ON	OFF	ON	OFF	OFF
148 149	ON OFF	ON ON	OFF OFF	ON ON	OFF OFF	ON ON	ON ON	OFF OFF		212 213	ON OFF	ON ON	OFF OFF	ON ON	OFF OFF	ON ON	OFF OFF	OFF OFF
149	ON	OFF	OFF	ON	OFF	ON	ON	OFF		213	ON	OFF	OFF	ON	OFF	ON	OFF	OFF
151	OFF	OFF	OFF	ON	OFF	ON	ON	OFF	1	215	OFF	OFF	OFF	ON	OFF	ON	OFF	OFF
152	ON	ON	ON	OFF	OFF	ON	ON	OFF		216	ON	ON	ON	OFF	OFF	ON	OFF	OFF
153	OFF	ON	ON	OFF	OFF	ON	ON	OFF		217	OFF	ON	ON	OFF	OFF	ON	OFF	OFF
154	ON OFF	OFF	ON ON	OFF OFF	OFF OFF	ON ON	ON ON	OFF OFF		218	ON OFF	OFF	ON ON	OFF OFF	OFF OFF	ON ON	OFF OFF	OFF OFF
155 156	OPP	OFF ON	OFF	OFF	OFF	ON	ON	OFF		219 220	OFF	OFF ON	OFF	OFF	OFF	ON	OFF	OFF
157	OFF	ON	OFF	OFF	OFF	ON	ON	OFF	1	221	OFF	ON	OFF	OFF	OFF	ON	OFF	OFF
158	ON	OFF	OFF	OFF	OFF	ON	ON	OFF		222	ON	OFF	OFF	OFF	OFF	ON	OFF	OFF
159	OFF	OFF	OFF	OFF	OFF	ON	ON	OFF		223	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF
160	ON OFF	ON ON	ON ON	ON ON	ON ON	OFF OFF	ON ON	OFF OFF		224	ON OFF	ON ON	ON ON	ON ON	ON ON	OFF OFF	OFF OFF	OFF OFF
162	ON	OFF	ON	ON	ON	OFF	ON	OFF		226	ON	OFF	ON	ON	ON	OFF	OFF	OFF
163	OFF	OFF	ON	ON	ON	OFF	ON	OFF	1	227	OFF	OFF	ON	ON	ON	OFF	OFF	OFF
164	ON	ON	OFF	ON	ON	OFF	ON	OFF		228	ON	ON	OFF	ON	ON	OFF	OFF	OFF
165	OFF ON	ON OFF	OFF OFF	ON ON	ON	OFF OFF	ON	OFF OFF		229	OFF ON	ON OFF	OFF OFF	ON	ON	OFF OFF	OFF OFF	OFF OFF
166 167	OFF	OFF	OFF	ON	ON ON	OFF	ON ON	OFF		230 231	OFF	OFF	OFF	ON ON	ON ON	OFF	OFF	OFF
168	ON	ON	ON	OFF	ON	OFF	ON	OFF		232	ON	ON	ON	OFF	ON	OFF	OFF	OFF
169	OFF	ON	ON	OFF	ON	OFF	ON	OFF		233	OFF	ON	ON	OFF	ON	OFF	OFF	OFF
170	ON	OFF	ON	OFF	ON	OFF	ON	OFF		234	ON	OFF	ON	OFF	ON	OFF	OFF	OFF
171	OFF ON	OFF ON	ON OFF	OFF OFF	ON ON	OFF OFF	ON ON	OFF OFF		235 236	OFF ON	OFF ON	ON OFF	OFF OFF	ON ON	OFF OFF	OFF OFF	OFF OFF
172	OFF	ON	OFF	OFF	ON	OFF	ON	OFF		230	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF
174	ON	OFF	OFF	OFF	ON	OFF	ON	OFF	l	238	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
175	OFF	OFF	OFF	OFF	ON	OFF	ON	OFF		239	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF
176	ON	ON	ON	ON	OFF	OFF	ON	OFF		240	ON	ON	ON	ON	OFF	OFF	OFF	OFF
177 178	OFF ON	ON OFF	ON ON	ON ON	OFF OFF	OFF OFF	ON ON	OFF OFF		241 242	OFF ON	ON OFF	ON ON	ON ON	OFF OFF	OFF OFF	OFF OFF	OFF OFF
170	OFF	OFF	ON	ON	OFF	OFF	ON	OFF		242	OFF	OFF	ON	ON	OFF	OFF	OFF	OFF
180	ON	ON	OFF	ON	OFF	OFF	ON	OFF	1	244	ON	ON	OFF	ON	OFF	OFF	OFF	OFF
181	OFF	ON	OFF	ON	OFF	OFF	ON	OFF		245	OFF	ON	OFF	ON	OFF	OFF	OFF	OFF
182	ON	OFF	OFF	ON	OFF	OFF	ON	OFF OFF		246	ON	OFF	OFF	ON	OFF	OFF	OFF	OFF
183 184	OFF ON	OFF ON	OFF ON	ON OFF	OFF OFF	OFF OFF	ON ON	OFF OFF		247 248	OFF ON	OFF ON	OFF ON	ON OFF	OFF OFF	OFF OFF	OFF OFF	OFF OFF
185	OFF	ON	ON	OFF	OFF	OFF	ON	OFF		240	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
186	ON	OFF	ON	OFF	OFF	OFF	ON	OFF	1	250	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF
187	OFF	OFF	ON	OFF	OFF	OFF	ON	OFF		251								
188	ON	ON	OFF	OFF	OFF	OFF	ON	OFF		252								
189 190	OFF ON	ON OFF	OFF OFF	OFF OFF	OFF OFF	OFF OFF	ON ON	OFF OFF		253 254								
190	OFF	OFF					ON	OFF		254								
191	OFF	UFF	OFF	OFF	OFF	OFF	UN	UFF		200								

Alternative Soft Addressing Option

Using our hand held MkII programmer (Part No: 48-004), the unit can be addressed electronically.

- Step 1: Set all addresses to zero 0000000
- Step 2: Connect leads to LOOP IN+ and LOOP IN- as shown below




Step 3: Follow the procedure as described in the handheld programmer manual.

NOTE: When a device is soft addressed as above, the address CANNOT BE CHANGED by mechanical setting of the dip-switch. In order to re-enable the dip-switch the unit needs to be set electronically back to zero first.

Isolator Function

The Isolator Function can be enabled or disabled according to the wiring method.

B. Enabling the Isolator Function



Functional Test Data

Command Bit	Function	Input Bit	Function
3	Not Used	3	Not Used
2	ENABLE SWITCH CLOSED LED 0 = Normal 1 = Illuminated Switch	2	Not Used
	Closed LED		
1	Not Used	1	OPTO INPUT
			0 = No Input
			1 = Voltage On Input
0	OPERATES RELAY	0	MONITORED INPUT
	0 = Relay On		0 = Quiescent
	1 = Relay Off		1 = Input Received

Input Condition and Status

Status	Load Input	Analogue	LED State	Input Bit. Bit 0
Short-circuit fault	<100Ω	8	Fault LED	=0
Indeterminate	100Ω-200Ω	8 or 72	1	=0 or 1
Switch closed	200Ω-11kΩ	136	Switch Closed	=1
Indeterminate	11kΩ-15kΩ	136 or 72	1	=0 or 1
Normal (Switch open)	15kΩ-25kΩ	72	-	0
Indeterminate	25kΩ-30kΩ	8 or 72	1	0
Open-circuit fault	>30kΩ	8	Fault LED	0

Analogue Return Back

Voltage Input	Analogue Value	LED State	Input Bit.Bit1
<1V	Irrelevant	Irrelevant	=0
1V-4V	Irrelevant	Irrelevant	=0/1
4V-35V	Irrelevant	Irrelevant	=1
>35V(not allowed)	Irrelevant	Irrelevant	/

Troubleshooting

Before investigating individual units for faults, it is very important to check that the system wiring is fault free. Many fault conditions are the result of simple wiring errors. Check all connections to the unit and make sure that the correct value resistors are fitted where necessary.

Faultfinding

Problem	Possible Cause
No response or missing	Incorrect address setting
	Incorrect loop wiring
Fault condition reported	Incorrect input wiring
Relay fails to operate	Control panel has incorrect cause and effect programming
	Incorrect address setting
Relay energized continuously	Incorrect loop wiring
	Incorrect address setting
Analogue value unstable	Dual address
	Loop data fault, data corruption
Constant alarm	Incorrect wiring
	Incorrect end-of-line resistor fitted
	Incompatible control panel software

Zeta Alarms Limited, 72-78 Morfa Road, Swansea SA1 2EN
0905 Zeta Alarms Limited,
Zeta Alarms Limited,
,
//-/8 Morta Road, Swansea SA1 /FN
14
14
GLT-233-DoP-1
EN54-18: 2005
EN54-17: 2005
Fire detection and fire alarm systems - Input/Output Devices
Fire detection and fire alarm systems - Short Circuit Isolators
Zeta Addressable Input Output Module with Isolator
ZAIO-MI
Intended for use in fire detection and fire alarm systems in and around buildings
Response delay (response time) - PASS
Performance under fire conditions - PASS
Operational reliability - PASS
Durability of operational reliability: temperature resistance - PASS
Durability of operational reliability; vibration resistance - PASS
Durability of operational reliability; humidity resistance - PASS
Durability of operational reliability; corrosion resistance - PASS
Durability of operational reliability; electrical stability - PASS